

DRY GLAZING

INSTALLATION INSTRUCTIONS

SIMPLICITY WITHIN COMPLEXITY

2025 - 2026















DRY GLAZING SYSTEMS - INSTALLATION











DRY GLAZING SYSTEMS - INSTALLATION

SMART SYSTEM

Innovative Features & Patented Elements

- * A UNIVERSAL CHANNEL DESIGN SIMPLE & SYMMETRIC adaptable to all site conditions with intermediary brackets.
- * LEVELING DEVICE integrated into the profile to ensure precise alignment
- * LEVELING DEVICE integrated into the profile to ensure precise alignment Easy glass positioning adjustment with a simple lever motion.

 This unique PATENT ALIGNMENT MECHANISM allow you know the glass angle by watching the lever direction.
- * POSITION & LOCK the glass panel, at any angle using our PATENT TRIPLE ACTION LOCKING SYSTEM.
 - Unique design grips top and bottom for maximum strength.
- * Our CLIP-ON cover solution suits all building types facades and designed to interface with any wall finish: Drywall, tiles, glass, wood, masonry, etc.

Why Choose Our System

- * Universal profile Minimal stock Maximum efficiency.
- * Multiple clip-on cover options compatible with every facade and wall finish.
- * Smart & Easy Balustrade Solutions Backed by Decades of Experience
- * Cantilever mount for a clean, floating look.
- * Unique alignment mechanism patent ensuring perfect glass line-up.
- * Triple action Patent locking system.
- * Our system's alignment and locking mechanism allow installation from inside the balcony, eliminating the need for lifting platforms and saving both TIME & MONEY.
- * Our dedicated team simplified the design and ordering process, making it easier than ever.
- * TÜV tested & certified.
- * Our system is comply with the ABZ German standard.

Simplicity Within Complexit


- * Not just developers, but installers With thousands of balcony and commercial projects delivered, we know how to simplify installation!!!
- * Smart & Easy Balustrade Solutions, Backed by 30+ Years of TOMAK Experience





PROFESSIONAL GRADE

SURFACE MOUNT INSTALLATION- TK-8400/ TK-8200 /TK-6200 The Base Shoe is pre-drilled to use with standard fasteners.



CAUTION:

IMPROPER MOUNTING OF ARCHITECTURAL RAILING RESULT IN FAILURE OR UNSAFE CONDITIONS



BASE MOUNTING INSTALLATION INSTRUCTION

STEP 1: LEVELING

Secure the base shoe firmly to the floor/ marvel / concrete - leveled substrate, Use only certified fasteners. During installation, continuously verify that the base shoe is level in both horizontal directions by using the Tomak Position Level (TP115).

Figure 1 – instaltion with out shims



Figure 2 – instaltion with shims



In case the substrate is not level and smooth, use metal shims beneath the base shoe to achieve proper leveling and complete the concrete fill underneath.

STEP 2: DRILLING

Drilling in concrete shall be carried out according to the existing holes in the profile.

The following two options can be used:

- * Chemical Anchor: Ø14 mm or 9/16" hole for bolts with
- * Direct Concrete Screw: Ø12 mm or 15/32" hole for.



Figure 3 - Drilling holes



STEP 3: BOLT BONDING

Install the bolts into the cured chemical anchor, applying firm and steady pressure to ensure full engagement and secure fixation

Direct concrete screw 1/2" x 4"



Chemical Anchor threaded rod 1/2" x 4"



Figure 4 – installtion bolts



Figure 5 - cut view



IMPORTANT:

All fastener heads and building penetrations must be sealed with silicone before installing the glass.




STEP 4: TOMAK ALIGNMENT MECHANISM

Carefully insert the Tomak Alignment Mechanism into the base shoe, oriented toward the inside of the balcony. For each glass panel, position two Tomak Alignment Mechanisms, each placed 20 mm (1") from the panel edges.

Figure 6 – Position of Alignment Mechanis in base



Figure 7 – Position of Alignment MechanismAlignment Mechanis in base





STEP 5: TOMAK GLASS BACK SUPPORT

Insert the Tomak Glass back support into its designated frame slot, ensuring proper alignment, and verify stability after installation. Install the support gasket at 20 mm (0.8") spacing, with each strip length of 230 mm (9").

Figure 8 - Installtion gaps




Figure 9 – Glass back support





STEP 6: TOMAK COVER CLIPS

Insert 6 pcs Tomak Cover Clips on each side of the Base Shoe, spaced at 500 mm (20"), for a total of twelve (12) clips per Base Shoe.



Figure 10 - Cover clips

STEP 7: TOMAK TOP COVER

Insert the Tomak outer Aluminum Top Cover profile, ensuring proper alignment. Press it down firmly until it locks securely into the Tomak Cover Clips in the Base Shoe




Figure 11 – Top Covre Profile




Figure 12 – Press down to lock it




STEP 8: TOMAK FIXING GLASS

Install the glass panel into the Base Shoe, ensuring that the glass is properly inserted into the Tomak Alignment Mechanism positioned inside the Base Shoe.
Use the Tomak Fixing Handle (TGF125) at the center of the glass panel to secure it through the Tomak Glass Back Support.

Figure 13 – Tomak Fixing Handle



Figure 14 – Installing glass with Tomak Fixing Handle





STEP 9: TOMAK GLASS ALIGNMENT HANDLE

Use the Tomak Alignment Handle (TAL110) to achieve precise positioning and ensure optimal alignment during installation of the glass.

Figure 15 - Cut view





Figure 16 - All Positions





STEP 10: TOMAK LOCKING MECHANISM

Starting 100 mm (4") from the edge of the Base Shoe, insert the Tomak Locking Mechanism every 250 mm (10") along the glass from the balcony side. To ensure each mechanism is properly secure.

Place the Tomak Locking Tool over the locking mechanism and tighten it with a ratchet to firmly lock the glass in place.

Figure 17 – Postion of Locking Mechanisms





Figure 18 – Locking Mechanisem




Figure 19 - Cut View



STEP 11: TOMAK TOP COVER

Insert the Tomak Inner Aluminum Top Cover profile, ensuring proper alignment. Press it down firmly until it locks securely into the Tomak Cover Clips in the Base Shoe.

Figure 20 – Inner Aluminu m Top Cover profile




STEP 12: CONNECTING BASE SHOE PROFILES

To connect 2 profiles together insert 4 Tomak 1/2" x1/4" Aluminum connectors into the base shoe intended sluts by hammer.



Slide the next base shoe profile into the Tomak Aluminum connectors to achieve perfect alignment.





MAINTENANCE / REPLACEMENT INSTRUCTIONS

GLASS REMOVAL & REPLACEMENT

In case the glass needs to be removed and replaced (e.g., due to breakage, delamination, or height adjustment), the process can be performed quickly and easily using the patented Tomak Unlocking Tool (TL105), specifically designed for the locking mechanism.

NOTE: Ensure that only trained personnel carry out glass removal and replacement, following all site safety requirements.




TL 105



TOMAK TOOL BOX (INCLUDED)









TAL110

Tomak Position Level



TPL115

Tomak Rachet1/2 Lock



TRL120

Tomak Glass Fixing Handle



TGF125

Tomak Power Liver 1/2X500



TPL130

Tomak Glass Clamp



TH140

Tomak Sockets Bolt







TSB135 - 19 TSB140 - 17

TSB145 - 13

UnLock



Tomak Extention Soket Bolt 1/2



TEX150

Tomak Hammer



TH155





TÜV TEST RESULTS



Reportnumber 89211059-02 | 12th January 2016 16.A352 - EN1991-1-1



Testresults

Test results after execution of the test(s) according to National Annex A, Static horizontal loads on parapets and wall partitions acting as barriers and National Annex B, Impact loads on parapets and wall partitions acting as barriers at a difference of heights of EN 1991-1-1 [1, 2]:

National Annex A, Static horizontal loads

Requireme	Description of the requirement	Pass/ Fail/		
nt		n.a.		
EN 1991-1-	If a partition wall, acting as barrier is m			
1+National	height with the surrounding floor, the s			
Annex A	surrounding water, a separate line load			
	F _k , must be applied.			
	Rooms q _{rep}			
		Recommended	Test-	
		value	value	
Table 6.12	Rooms category A	0,5 kN/m		n.a.
		1 min		
	Rooms category B, C1	0,5 kN/m		n.a.
		1 min		
	Rooms category C2 to C4 and D	1,0 kN/m	1,15kN	Pass
		1 min		
	Rooms category C5	3,0 kN/m	3,45kN	Pass
		5 min		
	An additional load was tested for	4,35 kN/m	5,00kN	Pass
	future applications up to 4,35kN/m1,	5 min		
	where the maximum value of the			
	scale is 5,00kN. Higher loads are			
	possible, but this could not be tested.			


Reportnumber 89211059-03 l 12th January 2016 16.A352 - EN1991-1-1




National Annex B, Impact loads on parapets and partition walls acting as barrier.

Test	•	height	Height of impact from underside construction (floor level) in mm	Dim. W x H in mm
1	Middle of width and appr. 15cm below the upper edge of sample	1,00 m	Appr. 950 mm	1150x1100mm

Require- ment nr.	Description of requirement		Pass/ Fail/ n.a.
NEN-EN 1991-1- 1+National Annex B	If a partition wall, acting as barrier is manda with the surrounding floor, the surrounding to water, the prescribed impact load must be of		
		Gemeten/beoordeeld	
NEN-EN 1991-1- 1+National Annex B	The construction is capable of withstanding the impact load, if the soft body impactor is not penetrating the construction.	no penetration of construction	Pass
NEN-EN 1991-1- 1+National Annex B	and after execution of the test, the residual strength and consistency of the construction is still intact	consistency intact	Pass





Strength Analysis









Scan this qr

All rights reserved to TOMAK LTD. company



US patent















Sigstar | Branding & Graphic design

